

## Safety Instructions for Loudspeakers

Symbol X

### Intended Use

This loudspeaker is intended exclusively for sound reproduction in living rooms and outdoors. Only install and use the speaker as described in the operating instructions. Any other use (especially safety-related or medical applications as well as outdoor installation) is considered improper and may result in damage to property or personal injury.

### Installation

- Place on a flat and stable surface
- Do not expose to extreme moisture (strong water jets)
- Do not prolongedly expose to direct sunlight
- Do not expose to high temperatures, keep sufficient distance from heat sources (heaters, ovens, open fires and all appliances that generate heat)
- Do not expose to extreme cold

### Safety Precautions

- Ensure that the speakers stand securely.
- Wall mounting: Follow the instructions in the operating instructions. Ensure that the wall has sufficient load-bearing capacity. Only use fastening material that is suitable for the wall construction/condition of the wall. Only mount the speakers on a solid vertical wall. The wall bracket is not suitable for mounting on ceilings or sloping surfaces. Accidents, injuries or damage can occur if the wall mounting is not carried out correctly. Magnat is not liable for accidents, injuries or damage resulting from improper wall mounting.
- Avoid vibrations.
- Please ensure that the connection cables are laid safely. Cables must not be laid in the vicinity of traffic routes (areas where people are present or moving) or cross them.
- Do not place any objects on top of the speakers. Do not cover the speakers with cloths or similar.
- Magnetic components: Please keep objects that are sensitive to magnetism away or do not place the speakers near them (e.g. CRT televisions, hard disk drives, magnetic cards such as credit cards, etc.).

- Do not place the speakers in the immediate vicinity of network components (e.g. routers, repeaters) and devices with transformers. Electromagnetic interference can cause noise. Cell phones in the immediate vicinity can also cause noise.
- Ensure that the speakers are adequately ventilated. Ventilation and reflex tube openings must not be covered or blocked. Do not operate in closed shelves or cabinets.
- The speaker should only be operated at temperatures between 0°C and 40°C.
- Do not use any aggressive cleaning agents containing alcohol or solvents or abrasive cleaning agents.
- The rubber feet supplied may leave residues or marks on some material surfaces under unfavorable conditions (e.g. high room temperatures or humidity).
- The device or the housing must not be opened. Repair and maintenance work may only be carried out by qualified specialists.

### **Prevention of Hearing Damage**

Prolonged exposure to sound at high volumes can cause hearing damage or even permanent hearing loss. Please read the following safety instructions before using the speakers.

- When you switch on the speakers, set the volume control to the lowest possible volume to start with.
- Slowly increase the volume to a level that is comfortable for you.
- Always try to keep the volume as low as possible.
- If you experience discomfort or if you notice ringing in your ears, it is recommended that you stop using the speakers immediately.

#### **Manufacturer information:**

**Premium Audio Company Germany GmbH**

Lise-Meitner-Str. 9  
50259 Pulheim  
Germany  
[www.magnat.de](http://www.magnat.de)  
[info@premiumaudioco.com](mailto:info@premiumaudioco.com)

#### **Person responsible for the EU:**

**Premium Audio Company Germany GmbH**

Lise-Meitner-Str. 9  
50259 Pulheim  
Germany  
[www.magnat.de](http://www.magnat.de)  
[compliance@premiumaudioco.com](mailto:compliance@premiumaudioco.com)